



- #1 Flywheel replacement with monitor
- Flywheel replacement w/o monitor
- #2 Left footboard assy
- Left footboard only
- #3 Right footboard assy
- Right footboard only
- #4 Seat carriage (frame only)
- #6 Monorail
- #7 Seat top with screws
- #8 Straight arm
- #9 Bent arm
- #10 Front leg assy
- #11 Rear leg assy
- #12 Heel rest assy
- #13 Skewer assembly
- #14 Handle assy

- PN 275
- PN 352
- PN 28
- PN 117
- PN 29
- PN 118
- PN 64
- PN 241
- PN 1703
- PN 113
- PN 114
- PN 30
- PN 31
- PN 32
- PN 277
- PN 279

- #15 Seat screw
- #16 Fancage screw
- #17 Leg U-bolt
- #18 Leg U-bolt nut
- #19 Frame bolt (117.5mm)
- #20 Frame bolt (127.5mm)
- #21 Frame bolt nuts
- #23 Handle U-bolt
- #24 Heel rest only
- #25 Monorail skewer screws
- #26 Handle U-bolt nut
- #27 Heel rest bolt
- " " wing nut
- " " washer
- #28 Handle hook
- #29 Handle hook cover

- PN 256
- PN 253
- PN 383
- PN 384
- PN 126
- PN 127
- PN 128
- PN 244
- PN 122
- PN 215
- PN 240
- PN 123
- PN 124
- PN 125
- PN 135
- PN 136